



CAN-AM SPARE TIRE MOUNT

2018+ Spare Tire Mount for Can-Am
Maverick X3

90201230



INSTALLATION MANUAL

INTRODUCTION

Thank you for your purchase of the BulletProof Spare Tire Rack for your Can-Am!

Pre-caution

Upon completing the installation of the tire rack, you should be able to accommodate a full size spare tire safely.

Warranty

At Neal Technologies, Inc. we know that if we don't take care of the customer, someone else will. That is why we strive to make each and every customer experience as wonderful as possible.

With regards to the BulletProof Tire Rack, we offer a 1-Year Parts-Only Warranty.

The limitations include:

- Parts-only, exchange-only warranty.
- Warranty is limited to defects in workmanship and materials.
- Shipping is NOT included with warranty returns.

In the rare event that you might have a warranty claim, we will be more than happy to assist you. Please call before you take action. We want to track and properly handle any warranty claims. You will need to contact our team at 888-967-6653 or 480-247-2331 so we will help you with your options and return.

Tools needed for installation

- 13mm Wrench
- 5mm Hex Head
- 10mm Socket
- 1/4" Ratchet
- 3/8" Drill Bit
- Drill

Parts List - 2022 + Spare Tire Mount for Can-Am Maverick X3


Part#	Description	Qty.
90201230	Can-AM Spare Tire Mount	1
6200251	Hex Drive Screws - M8x1.25 x 70mm	2
6200252	Hex Drive Screws - M8x1.25 x 40mm	2
6200253	Oversized, Flat Washer, 8.4MM ID x 21mm OD x 4mm	4
6200254	Locknut, Nylon Insert, Flanged M8x1.25	4

INSTALLATION INSTRUCTIONS



1. Remove the two nuts and bolts as indicated in the photo. *Hold onto nuts while loosening bolt to avoid losing them.



2. Drill out both rear holes using a 3/8" drill bit.



3. Remove the four heat shield bolts on the passenger side.

4. Place rack on the back cover as shown, lining up the holes with the rack.





5. Use the 2 supplied shorter screws, 4 washers and 2 of the nuts to secure the front tabs. Hand tighten.

6. Use the 2 provided longer screws and two nuts on the rear holes. Tighten.

- Tighten the front screws.
- Reinstall and tighten the heat shield screws.
- You are now ready to install your full-sized spare!



480.247.2331 • 888.967.6653 • bulletproofdiesel.com

